



Aurora Municipal Airport
 43W730 US Rt. 30
 Sugar Grove, IL 60554
 (630)-584-3200

Avionics/Instrument Test and Repair Capabilities List

Don't see your model on our list, gives us a call we are always adding more.

MANUFACTURER	PART #	MODEL	DESCRIPTION	TEST	REPAIR
ARC (Cessna)		1000 Series		•	
ARC (Cessna)		300 A System		•	•
ARC (Cessna)	47240-XXXX	B445	Converter	•	•
ARC (Cessna)	41790-XXXX	B841A	Converter	•	•
ARC (Cessna)	37960-1120	C530A	Autopilot Controller	•	•
ARC (Cessna)	41090-1128	C531A	Autopilot Controller	•	•
ARC (Cessna)	41780-XXXX	C830FD	Autopilot Controller	•	•
ARC (Cessna)	43110-XXXX	C876A	DME Indicator/Control	•	•
ARC (Cessna)	42310-XXXX	CA 295A	Autopilot Computer	•	•
ARC (Cessna)	43610-XXXX	CA 295B	Autopilot Computer	•	•
ARC (Cessna)	42660-XXXX	CA 395A	Autopilot Computer	•	•
ARC (Cessna)	41120-XXXX	CA 530A	Autopilot Computer	•	•
ARC (Cessna)	41120-XXXX	CA 530FD	Autopilot Computer	•	•
ARC (Cessna)	42860-XXXX	CA 550A	Autopilot Computer	•	•
ARC (Cessna)	40760-XXXX	G502A	Directional Gyro	•	•
ARC (Cessna)	37570-XXXX	G519A	Attitude Gyro	•	•
ARC (Cessna)	37570-XXXX	G519B	Altitude Gyro	•	•
ARC (Cessna)	44670-XXXX	G550A	Attitude Indicator	•	•
ARC (Cessna)	47070-XXXX	G1050A	Altitude Gyro	•	•
ARC (Cessna)	44690-XXXX	IG832A	HSI	•	•
ARC (Cessna)	46860-XXXX	IN 385 A/AC	Converter/Indicator	•	•
ARC (Cessna)	46860-XXXX	IN 386 A/AC	Converter/Indicator	•	•
ARC (Cessna)	42330-XXXX	PA 295A/B	Actuator	•	•
ARC (Cessna)	45850-XXXX	PA 495A/B	Actuator	•	•
ARC (Cessna)	42410-XXXX	R402A	Marker Receiver	•	•
ARC (Cessna)	41650-XXXX	R443A	Glideslope Receiver	•	•
ARC (Cessna)	42100-0000	R443B	Glideslope Receiver	•	•
ARC (Cessna)	43340-XXXX	RT 328	NAV/COM	•	•
ARC (Cessna)	41420-XXXX	RT 359A	ATC Transponder	•	•
ARC (Cessna)	46660-XXXX	RT 385A	VHF Nav/Com	•	•
ARC (Cessna)	43330-XXXX	RT428A	Transceiver	•	•

MANUFACTURER	PART #	MODEL	DESCRIPTION	TEST	REPAIR
ARC (Cessna)	41470-XXXX	RT 459A	ATC Transponder	●	●
ARC (Cessna)	47360-XXXX	RT 485A	Nav/Com/Tranceiver	●	●
ARC (Cessna)	49250-XXXX	RT 485B	Nav/Com/Tranceiver	●	●
ARC (Cessna)	42260-XXXX	RT 859A	Transponder	●	●
ARC (Cessna)	44000-XXXX	RTA 476A	DME Receiver Transmitter	●	●
ARC (Cessna)	46100-XXXX	RTA 876A	DME Receiver Transmitter	●	●
ARC (Cessna)	42710-0000	S 550A	Mode Selector	●	●
ARC (Cessna)	43380-XXXX	SP 105B	Synchrophaser	●	●
ARC (Cessna)	44430-2825	TA 495A	Trim Actuator	●	●
Avidyne	850-00010-XXX	EX500	MFD	●	
Avidyne		Flight Max	MFD/Radar		
Bendix	4000288-XXXX	CA-814A	Computer	●	●
Bendix	4000256-XXXX	FC-813A	Flight Controller	●	●
Bendix	4000256-XXXX	FC-813B	Flight Controller	●	●
Bendix	4000256-XXXX	FC-813C	Flight Controller	●	●
Bendix	4000256-XXXX	FC-813D	Flight Controller	●	●
Bendix	4000315-XXXX	FC-823A	Flight Controller	●	●
Bendix	4000315-XXXX	FC-823B	Flight Controller	●	●
Bendix/King	4000965-0204	IN 1302A	Radar Indicator	●	●
Bendix/King	066-3114-XX	IN 812A	RDS 81 Radar System	●	●
Bendix/King	622-2082-XXX	IND 350	NAV Indicator		
Bendix/King	622-2083-XXX	IND 351	NAV Indicator		
Bendix/King	065-5006-XX	KA 117	Trim Adapter	●	●
Bendix/King	071-1095-XX	KA 118	Demodulator	●	
Bendix/King	066-1089-XX	KA 120	Antenna	●	
Bendix/King	071-1285-XX	KA 128	KWX 58 Radar System	●	●
Bendix/King	071-2009-02	KA 134	Audio Control	●	
Bendix/King	065-5020-XX	KA 142	Trim Adapter	●	●
Bendix/King	065-0058-XX	KA 185	Annunciator	●	●
Bendix/King	066-3076-XX	KA 248	KWX 58 Radar System	●	
Bendix/King	071-2004-XX	KA 25	Isolation Amplifier	●	
Bendix/King	065-0032-XX	KA 285	Autopilot Controller	●	●
Bendix/King	071-1041-XX	KA 39	Power Converter	●	●
Bendix/King	071-1055-XX	KA 52	Autopilot Adapter	●	●
Bendix/King	071-0017-XX	KA 57	Autopilot Accessory	●	●
Bendix/King	071-01545-XXXX	KA 91	Antenna	●	
Bendix/King	071-01553-XXXX	KA 92	Antenna	●	
Bendix/King	071-2007-XX	KA 445	Audio System	●	●
Bendix/King	065-00176-XXXX	KC 140 (System)	Autopilot Computer	●	
Bendix/King	065-0055-XX	KC 190	Autopilot Computer	●	●
Bendix/King	065-0054-XX	KC 191	Autopilot Computer	●	●
Bendix/King	065-0042-XX	KC 192	Autopilot Computer	●	●
Bendix/King	065-0033-XX	KC 290	Mode Controller	●	●
Bendix/King	065-0035-XX	KC 291	Yaw Control	●	●

MANUFACTURER	PART #	MODEL	DESCRIPTION	TEST	REPAIR
Bendix/King	065-0037-XX	KC 292	Mode Controller	●	●
Bendix/King	065-0034-XX	KC 295	Autopilot Computer	●	●
Bendix/King	065-0036-XX	KC 296	Autopilot Computer	●	●
Bendix/King	065-0045-XX	KCP 299	Autopilot Computer	●	●
Bendix/King	071-1217-XX	KDA 692	Data Adapter	●	●
Bendix/King	066-1077-XX	KDF 806	ADF Receiver	●	●
Bendix/King	066-3032-XX	KDI 571	DME Indicator	●	●
Bendix/King	066-1069-XX	KDI 572	DME Indicator	●	●
Bendix/King	066-1069-XX	KDI 573	DME Indicator	●	●
Bendix/King	066-1069-XX	KDI 574	DME Indicator	●	●
Bendix/King	066-1019-XX	KDM 7000	DME	●	●
Bendix/King	066-1019-XX	KDM 7000A	DME	●	●
Bendix/King	066-1037-XX	KDM 705	DME Transceiver	●	●
Bendix/King	066-1037-XX	KDM 705A	DME Transceiver	●	●
Bendix/King	066-1066-XX	KDM 706	DME Transceiver	●	●
Bendix/King	066-1066-XX	KDM 706A	DME Transceiver	●	●
Bendix/King	064-01088-XXXX	KDR 510	NAV Data Receiver	●	●
Bendix/King	066-3064-XX	KEA 129	Altimeter	●	●
Bendix/King	066-3064-XX	KEA 130	Altimeter	●	●
Bendix/King	066-3064-XX	KEA 130A	Altimeter	●	●
Bendix/King	066-3062-XX	KEA 346	Encoding Altimter	●	●
Bendix/King		KFC 150 (System)	Autopilot	●	●
Bendix/King		KFC 200 (System)	Autopilot	●	●
Bendix/King		KFC 250 (System)	Autopilot	●	●
Bendix/King	071-1216-XX	KFS 564	Nav Control	●	●
Bendix/King	071-1043-XX	KFS 570B	Transponder Control	●	●
Bendix/King	071-1192-XX	KFS 576	Transponder Control	●	●
Bendix/King	071-1210-XX	KFS 586	ADF Control	●	●
Bendix/King	071-1215-XX	KFS 598	Com Control	●	●
Bendix/King	060-0015-XX	KG 102A	Directional Gyro	●	●
Bendix/King	060-0016-XX	KG 102A	Directional Gyro	●	●
Bendix/King	060-0022-XX	KG 107	Directional Gyro	●	●
Bendix/King	071-4027-XX	KG 257	Directional Gyro	●	●
Bendix/King	066-1006-00	KGM 690	Glideslope MKR Receiver	●	●
Bendix/King	066-1035-XX	KGM 691	Glideslope MKR Receiver	●	●
Bendix/King	066-1005-00	KGS 680	Glideslope Receiver	●	●
Bendix/King	066-1036-00	KGS 681	Glideslope Receiver	●	●
Bendix/King	066-3008-XX	KI 201	NAV Indicator	●	●
Bendix/King	066-3034-XX	KI 202	NAV Indicator	●	●
Bendix/King	066-3034-XX	KI 203	NAV Indicator	●	●
Bendix/King	066-3034-XX	KI 204	NAV Indicator	●	●
Bendix/King	066-3039-XX	KI 205	NAV Indicator	●	●
Bendix/King	066-3034-XX	KI 206	NAV Indicator	●	●
Bendix/King	066-3034-XX	KI 207	NAV Indicator	●	●
Bendix/King	066-3056-XX	KI 208	NAV Indicator	●	●
Bendix/King	066-3056-XX	KI 208A	NAV Indicator	●	●

MANUFACTURER	PART #	MODEL	DESCRIPTION	TEST	REPAIR
Bendix/King	066-3056-XX	KI 209	NAV Indicator	●	●
Bendix/King	066-3056-XX	KI 209A	NAV Indicator	●	●
Bendix/King	066-1010-XX	KI 211	NAV Indicator	●	●
Bendix/King	066-3025-00	KI 213	NAV Indicator	●	●
Bendix/King	066-3063-00	KI 227	ADF Indicator	●	●
Bendix/King	066-3059-XX	KI 228	ADF Indicator	●	●
Bendix/King	066-3038-XX	KI 229	RMI Conv/Indicator	●	●
Bendix/King	060-0017-XX	KI 256	Horizon Gyro	●	●
Bendix/King	066-3046-XX	KI 525A	HSI	●	●
Bendix/King		KLN 35	GPS	●	●
Bendix/King	070-1151-XX	KLN 35A	GPS	●	●
Bendix/King	066-01148-XXXX	KLN 89	GPS	●	●
Bendix/King	066-01148-XXXX	KLN 89B	GPS	●	●
Bendix/King	066-04031-XXXX	KLN 90	GPS	●	●
Bendix/King	066-04034-XXXX	KLN 900	GPS	●	●
Bendix/King	066-04031-XXXX	KLN 90A	GPS	●	●
Bendix/King	066-04031-XXXX	KLN 90B	GPS	●	●
Bendix/King	069-01034-XXXX	KLN 94	GPS	●	●
Bendix/King	069-01029-XXXX	KLX 135	GPS/COM Tranceiver	●	●
Bendix/King	070-01029-XXXX	KLX 135A	GPS/COM Tranceiver	●	●
Bendix/King	065-0030-XX	KM 275	Actuator Mount	●	●
Bendix/King	065-0031-XX	KM 276	Actuator Mount	●	●
Bendix/King	065-0041-XX	KM 277	Actuator Mount	●	●
Bendix/King	066-1024-XX	KMA 20	Audio/MKR Panel	●	●
Bendix/King	066-1055-XX	KMA 24	Audio/MKR Panel	●	●
Bendix/King	066-1055-XX	KMA 24H	Audio/MKR Panel	●	●
Bendix/King	066-01155-XXXX	KMA 26	Audio/MKR Panel	●	●
Bendix/King	066-01176-XXXX	KMA 28	Audio/MKR Panel	●	●
Bendix/King	066-01174-XXXX	KMD 150	MFD	●	●
Bendix/King	066-04036-XXXX	KMD 250	MFD	●	●
Bendix/King	066-04035-XXXX	KMD 540	MFD	●	●
Bendix/King	KMD0850-01	KMD 850	MFD	●	●
Bendix/King	066-1044-XX	KMR 675	Marker Receiver	●	●
Bendix/King	066-1067-XX	KN 53	VHF Nav Receiver	●	●
Bendix/King	066-1064-XX	KN 62	DME Transceiver	●	●
Bendix/King	066-1068-XX	KN 62A	DME Transceiver	●	●
Bendix/King	066-1070-XX	KN 63	DME Transceiver	●	●
Bendix/King	066-1088-XX	KN 64	DME Transceiver	●	●
Bendix/King	066-1029-XX	KN 65	DME Transceiver	●	●
Bendix/King	066-1029-XX	KN 65A	DME Transceiver	●	●
Bendix/King	069-1013-XX	KN 70	Glideslope Receiver	●	●
Bendix/King	066-4009-XX	KN 72	VOR/LOC Converter	●	●
Bendix/King	066-1033-00	KN 73	Glideslope Receiver	●	●
Bendix/King	066-1063-XX	KN 75	Glideslope Receiver	●	●
Bendix/King	066-4004-00	KN 77	VOR/LOC Converter	●	●
Bendix/King	071-1010-00	KNR 600	NAV Receiver	●	●

MANUFACTURER	PART #	MODEL	DESCRIPTION	TEST	REPAIR
Bendix/King	066-1010-00	KNR 600	NAV Receiver	●	●
Bendix/King	066-4007-XX	KNR 630	NAV Receiver	●	●
Bendix/King	066-4008-XX	KNS 80	RNAV System	●	●
Bendix/King	066-4010-XX	KNS 81	RNAV System	●	●
Bendix/King		KR 20		●	●
Bendix/King	066-1021-XX	KR 21	Marker Receiver	●	●
Bendix/King	066-01072-XXXX	KR 87	ADF Receiver	●	●
Bendix/King	066-1061-XX	KRA 10A	Radio Altimeter	●	●
Bendix/King	065-0050-XX	KS 177	Servo Actuator	●	●
Bendix/King	065-0051-XX	KS 178	Servo Actuator	●	●
Bendix/King	065-0052-XX	KS 179	Servo Actuator	●	●
Bendix/King	065-0027-XX	KS 270	Servo Actuator	●	●
Bendix/King	065-0059-XX	KS 270A	Servo Actuator	●	●
Bendix/King	065-00178-XX00	KS 270C	Servo Actuator	●	●
Bendix/King	065-0028-XX	KS 271	Servo Actuator	●	●
Bendix/King	065-0060-XX	KS 271A	Servo Actuator	●	●
Bendix/King	065-00179-XX00	KS 271C	Servo Actuator	●	●
Bendix/King	065-0029-XX	KS 272	Servo Actuator	●	●
Bendix/King	065-0061-XX	KS 272A	Servo Actuator	●	●
Bendix/King	065-00180-XX00	KS 272C	Servo Actuator	●	●
Bendix/King	065-0040-XX	KS 273	Yaw Servo	●	●
Bendix/King	065-0014-XX	KSA 370	Servo Actuator	●	●
Bendix/King	065-0024-XX	KSA 371	Servo Actuator	●	●
Bendix/King	060-0013-XX	KSG 105	Directional Gyro	●	●
Bendix/King	066-01141-XXXX	KT 70	ATC Transponder	●	●
Bendix/King	066-01141-XXXX	KT 71	ATC Transponder	●	●
Bendix/King		KT 74	ATC Transponder	●	●
Bendix/King	066-1034-XX	KT 76	ATC Transponder	●	●
Bendix/King	066-1062-XX	KT 76A	ATC Transponder	●	●
Bendix/King	066-01156-XXXX	KT 76C	ATC Transponder	●	●
Bendix/King	066-1034-XX	KT 78	ATC Transponder	●	●
Bendix/King	066-1062-XX	KT 78A	ATC Transponder	●	●
Bendix/King	066-1053-XX	KT 79	ATC Transponder	●	●
Bendix/King	064-1012-XX	KT 96	Phone	●	●
Bendix/King		KTR 79		●	●
Bendix/King	064-1003-XX	KTR 900	COM Transceiver	●	●
Bendix/King	064-1009-XX	KTR 905	COM Transceiver	●	●
Bendix/King	064-1023-XX	KTR 908	COM Transceiver	●	●
Bendix/King	071-5044-XX	KTS 143(#1-14)	Test Set	●	●
Bendix/King	069-01028-XXXX	KX 125	NAV/COM	●	●
Bendix/King	069-1022-00	KX 145	NAV/COM	●	●
Bendix/King	069-1024-XX	KX 155	NAV/COM	●	●
Bendix/King	069-01032-XXXX	KX 155A	NAV/COM	●	●
Bendix/King	069-1025-XX	KX 165	NAV/COM	●	●
Bendix/King	069-01033-XXXX	KX 165A	NAV/COM	●	●
Bendix/King	069-1014-00	KX 170	NAV/COM	●	●

MANUFACTURER	PART #	MODEL	DESCRIPTION	TEST	REPAIR
Bendix/King	069-1017-00	KX 170A	NAV/COM	●	●
Bendix/King	069-1020-00	KX 170B	NAV/COM	●	●
Bendix/King	069-1020-01	KX 170BE	NAV/COM	●	●
Bendix/King	069-1016-XX	KX 175	NAV/COM	●	●
Bendix/King	069-1016-XX	KX 175A	NAV/COM	●	●
Bendix/King	069-1019-00	KX 175B	NAV/COM	●	●
Bendix/King	069-1019-01	KX 175BE	NAV/COM	●	●
Bendix/King	066-1011-00	KXP 750	Transponder	●	●
Bendix/King	066-1025-XX	KXP 750A	Transponder	●	●
Bendix/King	066-1041-XX	KXP 755	Transponder	●	●
Bendix/King	066-1071-XX	KXP 756	Transponder	●	●
Bendix/King	064-1019-XX	KY 196	VHF Transceiver	●	●
Bendix/King	064-1054-XX	KY 196A	VHF Transceiver	●	●
Bendix/King	064-1019-XX	KY 196E	VHF Transceiver	●	●
Bendix/King	064-1021-XX	KY 197	VHF Transceiver	●	●
Bendix/King	064-1053-XX	KY 197A	VHF Transceiver	●	●
Bendix/King	064-1021-XX	KY 197E	VHF Transceiver	●	●
Bendix/King	064-1020-XX	KY 92	VHF Transceiver	●	●
Bendix/King		KY 96	VHF Transceiver	●	●
Bendix/King	064-1052-XX	KY 96A	VHF Transceiver	●	●
Bendix/King		KY 97	VHF Transceiver	●	●
Bendix/King	064-1051-XX	KY 97A	VHF Transceiver	●	●
Bendix	4000289-XXXX	PS-815A	Power Supply	●	●
Bendix	4000289-XXXX	PS-815B	Power Supply	●	●
Bendix	4000289-XXXX	PS-815V	Power Supply	●	●
Bendix	4000293-XXXX	PS-819	Power Adapter	●	●
Bendix/King		RDR 150	Radar System	●	●
Bendix/King		RDR 160	Radar System	●	●
Bendix/King		RDR 2000	Radar System	●	●
Bendix/King		RDR 2100	Radar System	●	●
Bendix/King		RDS 81	Radar System	●	●
Bendix/King		RDS 82	Radar System	●	●
Bendix/King		RDS 84	Radar System	●	●
Bendix/King		RDS 86	Radar System	●	●
Bendix/King	071-1378-XX	RS 811A	RDS 81 Radar System	●	●
Bendix	4000290-XXXX	SA-816A	Servo Actuator	●	●
Bendix	4000291-XXXX	SE-816A	Servo Actuator	●	●
Bendix	4000292-XXXX	ST-816A	Servo Actuator	●	●
Bendix	4000292-XXXX	ST-816B	Servo Actuator	●	●
Bendix	4000292-XXXX	ST-816C	Servo Actuator	●	●
Bendix	4000292-XXXX	ST-816D	Servo Actuator	●	●
Bendix	4000292-XXXX	ST-816E	Servo Actuator	●	●
Bendix/King		TPR 2060		●	
Bendix/King		TPR 611		●	
Bendix/King		TPR 641		●	
Bendix/King		TPR 660		●	

MANUFACTURER	PART #	MODEL	DESCRIPTION	TEST	REPAIR
Century		1C338	A/P Computer	●	●
Century		1C363	Servo	●	●
Century		1C373	Servo	●	●
Century		1C465	Servo	●	●
Century		1C469 1	Actuator	●	●
Century		1C469 2	Actuator	●	●
Century		1C469 3	Actuator	●	●
Century		1C470	Servo	●	●
Century	1C497-8	1C497-8	A/P Controller	●	●
Century		1C508	Servo	●	●
Century		1C543-1	A/P Coupler	●	
Century		1D496	A/P Computer	●	
Century		52D136	HSI	●	●
Century		52D137	HSI	●	●
Century		52D254	Attitude Gyro	●	●
Century		52D266	Attitude Gyro	●	●
Century		52D267	Attitude Gyro	●	●
Century	1U262-003-XX	52D54	Directional Gyro	●	●
Century	700-2CF	52D66	Horizon Reference Indicator	●	●
Century	700-2CF	52D67	Horizon Reference Indicator	●	●
Century		52D75	Turn Coordinator	●	●
Century	Century I	I System	Autopilot	●	●
Collins	622-2087-XXX	AMR 350	Audio/MKR Panel	●	
Collins	622-2462-XXX	AMR 350H	Audio/MKR Panel	●	
Collins	622-3767-XXX	ANS 351	Computer		
Collins	622-4523-XXX	CTL 20	Nav Control		
Collins	622-1233-XXX	DME 40	DME Indicator	●	
Collins	622-6263-XXX	DME 42	DME	●	
Collins	622-284-001	GLS 350	Glideslope Receiver	●	
Collins	622-3366-001	GLS 350E	Glideslope Receiver	●	
Collins	622-2082-XXX	IND 350	Course Indicator	●	
Collins		IND 350C	Course Indicator	●	
Collins	622-4477-XXX	IND 351	Course Indicator	●	
Collins	622-4478-XXX	IND 351A	Course Indicator	●	
Collins	622-3670-001	TCR 451	DME Transceiver	●	
Collins	622-1270-XXX	TDR 90	ATC Transponder	●	
Collins	622-2092-XXX	TDR 950	Transponder	●	
Collins	792-6657-XXX	VHF 20	VHF Transceiver	●	
Collins	622-1879-XXX	VHF 20A	VHF Transceiver	●	
Collins	622-1334-XXX	VHF 20B	VHF Transceiver	●	
Collins	622-6390-XXX	VHF 21B	VHF Transceiver	●	
Collins		VHF 22	VHF Transceiver	●	
Collins	622-6152-XXX	VHF 22A	VHF Transceiver	●	
Collins	622-6153-XXX	VHF 22B	VHF Transceiver	●	

MANUFACTURER	PART #	MODEL	DESCRIPTION	TEST	REPAIR
Collins	822-1113-XXX	VHF 22C	VHF Transceiver	●	
Collins	622-2079-XXX	VHF 250	VHF Transceiver	●	
Collins	622-2078-XXX	VHF 251	VHF Transceiver	●	
Collins	622-0876-XXX	VIR 30A	Nav Receiver	●	●
Collins	622-6137-001	VIR 32	Nav Receiver	●	●
Collins	622-2081-XXX	VIR 350	Nav Receiver	●	●
Collins	622-2080-XXX	VIR 351	Nav Receiver	●	●
David Clark		ISOCOM		●	
Edo Aire/Mitchell		1C318-194	A/P Computer	●	
Edo Aire/Mitchell	1C385	1C385	A/P Computer	●	●
Edo Aire/Mitchell		1C385IIB	A/P Computer	●	●
Edo Aire/Mitchell		1C404	A/P Controller	●	●
Edo Aire/Mitchell		1C407	A/P Computer	●	●
Edo Aire/Mitchell	1C515	1C515	A/P Computer	●	●
Edo Aire/Mitchell	1C515-1	1C5151	A/P Computer	●	●
Edo Aire/Mitchell	1C709	1C709	A/P Computer	●	●
Edo Aire/Mitchell	1D395	1D395	A/P Computer	●	●
Edo Aire/Mitchell	1C388	1C388	A/P Coupler	●	●
Edo Aire/Mitchell	1C388-1	1C3881	A/P Coupler	●	●
Edo Aire/Mitchell	1C388-2	1C3882	A/P Coupler	●	●
Edo Aire/Mitchell	1C388-3	1C3883	A/P Coupler	●	●
Edo Aire/Mitchell	1C388-M	1C388M	A/P Coupler	●	●
Garmin	430-0256-XX	360GPS	GPS	●	●
Garmin	430-6100-XX	CNX 80/GNS 480	GPS/NAV/COM	●	●
Garmin	011-00986-XX	GDL 69	Datalink Receiver	●	
Garmin	011-00987-XX	GDL 69A	Datalink Receiver	●	
Garmin	013-00049-XX	GI 106A	CDI	●	
Garmin		GI 201A	CDI	●	
Garmin	011-00401-XX	GMA 340	Audio Panel	●	●
Garmin	011-00807-XX	GMA 347	Audio Panel	●	●
Garmin	010-00483-XX	GMX 200	MFD	●	●
Garmin	010-00571-XX	GMX 200	MFD-Traffic	●	●
Garmin	010-00486-XX	GMX 200	MFD-Radar/TAWS	●	●
Garmin	010-00487-XX	GMX 200	MFD-Traffic/Radar	●	●
Garmin	011-00082-XX	GNC 250	NAV/Com	●	●
Garmin	011-00295-XX	GNC 250XL	Navigation Receiver	●	●
Garmin	011-00128-XX	GNC 300	Navigation Receiver	●	●
Garmin	011-00433-XX	GNC 300XL	GPS	●	●
Garmin	010-00139-XX	GNS 430	GPS/NAV/COM	●	●
Garmin	011-01060-XX	GNS 430(W)	GPS/WAAS/NAV/COM	●	●
Garmin	011-00550-XX	GNS 530	Navigation Receiver	●	●
Garmin	011-01064-XX	GNS 530(W)	Receiver w/WAAS	●	●
Garmin		GPS 100	GPS	●	●

MANUFACTURER	PART #	MODEL	DESCRIPTION	TEST	REPAIR
Garmin	010-00062-XX	GPS 150	GPS	●	●
Garmin	011-00345-XX	GPS 150XL	GPS	●	●
Garmin	011-00104-XX	GPS 155	GPS	●	●
Garmin	011-00412-XX	GPS 155XL	GPS	●	●
Garmin	011-02254-00	GTN 625	Touchscreen GPS/Nav/Com	●	●
Garmin	011-02255-00	GTN 635	Touchscreen GPS/Nav/Com	●	●
Garmin	011-02256-XX	GTN 650	Touchscreen GPS/Nav/Com	●	●
Garmin	011-02281-00	GTN 725	Touchscreen GPS/Nav/Com	●	●
Garmin	011-02282-XX	GTN 750	Touchscreen GPS/Nav/Com	●	●
Garmin	010-00135-XX	GTX 320	Transponder	●	●
Garmin	010-00247-00	GTX 320 A	Transponder	●	●
Garmin	011-00490-XX	GTX 327	Transponder	●	●
Garmin	011-00455-XX	GTX 330	Transponder	●	●
Garmin	011-00455-XX	GTX 330D	Transponder	●	●
Garmin		GX 50	GPS	●	●
Garmin	430-6050-XXX	GX 55	GPS/COM Transceiver	●	●
Garmin	430-6050-XXX	GX 60	GPS/COM Transceiver	●	●
Garmin	430-6050-XXX	GX 65	GPS/COM Transceiver	●	●
Garmin	430-0270-XXX	MX 20	MFD	●	●
Garmin	430-6040-XX	SL 30	NAV/COM Transceiver	●	●
Garmin	430-6040-XX	SL 40	COM	●	●
L3/BFG	78-8060-XXXX-X	WX 1000	Stormscope	●	
L3/BFG	805-11500-XXX	WX 500	Stormscope	●	
L3/BFG		WX 8	Stormscope	●	●
L3/BFG		WX 9	Stormscope	●	●
L3/BFG	78-8041-XXXX-X	WX 10	Stormscope	●	●
L3/BFG	78-8047-XXXX-X	WX 10A	Stormscope	●	●
L3/BFG	78-8047-XXXX-X	WX 11	Stormscope	●	●
L3/BFG		WX 900	Stormscope	●	
L3/BFG		WX 950	Stormscope	●	
Mid-Continent	MD41-XXXX	MD 41	Annunciator	●	
Narco	AT-150	AT 150	ATC Transponder	●	●
Narco		AT 50	ATC Transponder	●	●
Narco		AT 50A	ATC Transponder	●	●
Narco		COM 10	COM	●	●
Narco		COM 11	COM	●	●
Narco		COM 810	VHF Transceiver	●	●
Narco		COM 811	COM	●	●
Narco		CP 125		●	●
Narco		CP 126		●	●
Narco		CP 135		●	●
Narco		CP 136		●	●
Narco		DME 190		●	

MANUFACTURER	PART #	MODEL	DESCRIPTION	TEST	REPAIR
Narco		DME 195		•	
Narco		DME 890	DME Indicator	•	
Narco		DME 891		•	
Narco		E 110			
Narco		ESCORT 2			
Narco		KWX 56	Radar	•	•
Narco		KWX 58	Radar	•	•
Narco		MBT 12		•	•
Narco		MK 12D	VHF NAV/COM	•	•
Narco		MKR 101		•	
Narco		MP 10		•	
Narco		NAV 11		•	•
Narco		NAV 12		•	•
Narco		NAV 121	NAV/CDI	•	•
Narco		NAV 122		•	•
Narco		NAV 124		•	•
Narco		NAV 14		•	
Narco		NAV 824	VHF Nav Receiver	•	
Narco		NAV 825	VHF Nav Receiver	•	
Narco		NCS 812		•	
Narco		NS 800		•	
Narco		UGR 2		•	
Narco		UGR 3		•	
Primus	MI-585147-1	20	Radar Indicator	•	
Primus	MI-585149-X	20	Radar R/T	•	
Primus	MI-585210-X	20	Radar Indicator	•	
Primus	MI-585157	20	Radar Antenna	•	
Primus	MI-585171	20	Radar Indicator	•	
Primus	MI-585191-2	20	Radar Indicator	•	
Primus	MI-585148-X	20	Radar Antenna	•	
Primus	MI-585136-1	40	Radar Antenna	•	
Primus	MI-585134-X	40	Radar Indicator	•	
Primus	MI-585135-X	40	Radar Indicator	•	
Primus	MI-585322-X	100	Radar Indicator	•	
Primus	MI-585439-X	150	Indicator	•	
Primus	MI-585438-X	150	Indicator	•	
Primus		200		•	
Primus		300		•	
Primus		400		•	
Primus		800		•	
S-TEC(Cobham)		55	Computer	•	
S-TEC(Cobham)		55X	Computer	•	•
S-TEC(Cobham)		System 40	Computer	•	
S-TEC(Cobham)		System 50	Computer	•	

MANUFACTURER	PART #	MODEL	DESCRIPTION	TEST	REPAIR
S-TEC(Cobham)		System 60	Computer	•	
S-TEC(Cobham)		System 60-1	Computer	•	
S-TEC(Cobham)		System 60-2	Computer	•	
S-TEC(Cobham)		System 65	Computer	•	
S-TEC(Cobham)		System 60 PSS	Computer	•	
TKM	MX11	MX 11	Com	•	•
TKM	MX12	MX 12	Nav/Com	•	•
TKM	MX170B	MX 170 B	Nav/Com	•	•
TKM		MX 170 C	Nav/Com	•	•
TKM	MX300	MX 300	Nav/Com	•	•
TKM	MX385	MX 385	Nav/Com	•	•

